

ATTRACT

Attract new voters during election campaigns. Present candidates on a Flag Pole or Tent.

NAVIGATE

Navigate voters inside the polling station. Use Floorstickers, a Tablet Holder and a Table Cover to navigate

SHOW

Show the entrance of the polling station. Use an A-board and Beach Flag to guide to the entrance.





ELECTIONS inspiration





FLAG POLE

- Large flag system
- Stable aluminium tripod base
- Water tank base





Strong lightweight portable aluminium tent Great solution for outdoor events

TENT ALU WITH CANOPY AND HALF WALL

WINDTALKER® CITY

- · Double-sided advertisement
- Easy and quick change of poster
- Plastic base for water- & sand filling



5

TABLE COVER STANDARD

Machine-washable and wrinkle resistant Ideal to use at events and demonstrations

Easy and quick to set up



- Tablet holder for Apple iPad 10.2" (2019) and Samsung Galaxy Tab 10.1" (2019)
- · Easy and fast installation
- Lockable





- · Latex print sticker with customised print designs
- Available in round and stripe shape
- · Easy to use on any flat surface







- Disinfection holder with Snap Frame
- Manual soap dispenser
- Adjustable in height





- **ROLL-BANNER OPEN-AIR**
- Outdoor banner
- Double-sided





Easy and quick to set up

diameter with rotator · Stylish steel plate base

Thick aluminium flag pole of 28 mm





25 MM A-BOARD DESIGN STANDARD

- Suitable for indoor use or covered areas
- Bestseller A-Board
- · Double-sided advertisement

